



YY-6270

Item	Part Name	Q'TY	Part Code
1.	Chassis Sub-Assemble	1	0204-62002
2.	Top Cover	1	0205-62001
3.	80mm Fan	1	0602-00002
4.	ATX I/O Shield	1	5002-00002
5.	Fan Holder	1	0323-00001
6.	2.25" Speaker	1	0501-00001
7.	Filter	1	ZZ13-00001
8.	3.5" Drive Frame 3DH	1	0206-62010
9.	Power Supply Bracket	1	0205-62003
10.	Foot	4	ZZ05-00001
11.	Lock Plate	1	0214-12015
12.	Power Switch	1	0401-00004
13.	LED Cable	1	0404-53001
14.	LED Holder	1	0313-62001
15.	Reset Knob	1	ZZ32-00001
16.	LED Lens	1	ZZ33-00002
17.	3.5" Sub Panel	1	0303-62001
18.	Front Panel	1	0301-62005
19.	5.25" Cover Panel	3	0311-62005
20.	Power Knob	1	ZZ30-53007
21.	Spring	1	ZZ12-00001
22.	FDD Knob	1	ZZ31-00001
23.	FDD Lens	1	ZZ33-62001
24.	Standoff	5	0215-00003
25.	Pin	5	0323-00001

● Optional accessory




figure 11